



JOHN DEERE

OPERATOR'S MANUAL

**43" Drop Spreader
3-Pt Hitch Model**

LP64761
ST50968
04/05/22
English

Introduction

Using Your Operator's Manual

Read this entire operator's manual, especially the safety information, before operating.

This manual is an important part of your machine. Keep all manuals in a convenient location so they can be accessed easily.

Use the safety and operating information in the attachment operator's manual, along with the machine operator's manual, to operate and service the attachment safely and correctly.

If your attachment manual has a section called Preparing the Machine, it means that you will have to do something to your tractor or vehicle before you can install the attachment. The Assembly and Installation sections of this manual provide information to assemble and install the attachment to your tractor or vehicle. Use the Service section to make any needed adjustments and routine service to your attachment.

If you have any questions or concerns with the assembly, installation, or operation of this attachment, see your local John Deere dealer or call the John Deere Customer Contact Center at 1-800-448-9282 for assistance.

Warranty information on this John Deere attachment can be found in the warranty that came with your John Deere tractor or vehicle.

Table of Contents

Introduction	2
Product Identification	2
Safety Labels	3
Safety	5
Assembly	6
Installation	7
Operation	10
Maintenance	14
Removal & Storage	15
Troubleshooting	16
Wiring Diagram	21
Getting Quality Service	22
Warranty	22

Product Identification

Product Compatibility

Drop Spreader is compatible with 1023E and 1025R compact utility tractors.

Drop Spreader is compatible with 2025R beginning with model year 2018, serial number HH100001.


Original instructions. All information, illustrations and specifications in this manual are based on the latest information available at the time of publication.

The right is reserved to make changes at any time without notice.

Safety Labels

Safety Labels

Safety Label Location



Understanding The Machine Safety Labels



The machine safety labels shown in this section are placed in important areas on your machine to draw attention to potential safety hazards.

On your machine safety labels, the words **DANGER**, **WARNING**, and **CAUTION** are used with this safety-alert symbol. **DANGER** identifies the most serious hazards.

The operator's manual also explains any potential safety hazards whenever necessary in special messages that are identified with the word, **CAUTION**, and the safety-alert symbol.

Replace missing or damaged safety labels. Use this operator's manual for correct safety label placement.

There can be more safety information contained on parts and components sourced from suppliers that is not reproduced in this operator's manual.

French or Spanish Safety Labels and Operator's Manual

Operator's manuals and safety labels with content in French or Spanish are available for this machine through authorized John Deere dealers.

Warning

Avoid Injury From Moving Parts



- Keep hands, feet and clothing away
- Disconnect power before servicing

Safety Labels

Caution

Avoid Injury and Read Operator Manual Before Use



- Never remove spreader with material in hopper
- Maximum weight capacity 350 lb.

Caution

To Avoid injury, do not ride on platform



Safety

Read Safety in Machine Operator's Manual

Read the general safety operating precautions in your machine operator's manual for additional safety information.

Operating Safely

- Read the machine and attachment operator's manual carefully. Be thoroughly familiar with the controls and the proper use of the equipment. Know how to stop the machine and disengage the controls quickly.
- This attachment is intended for use in sidewalk and property maintenance applications. Do not use for use other than intended by the manufacturer.
- Do not modify machine or safety devices. Unauthorized modifications to the machine or attachment may impair its function and safety.

Operating Safely

- Do not let children or an untrained person operate machine.
- Make any necessary adjustments before you operate. Never attempt to make any adjustments while the engine is running, unless if recommended in adjustment procedure.
- Look behind machine before you back up. Back up carefully.
- Do not let anyone, especially children, ride on machine or attachment. Riders are subject to injury such as being struck by foreign objects and being thrown off. Riders may also obstruct the operator's view, resulting in the machine being operated in an unsafe manner.
- Disengage any power to the attachment when the machine is transported or not in use.

Parking Safety

1. Stop machine on a level surface, not on a slope.
2. Disengage mower blades or any other attachments.
3. Lower attachments to the ground.
4. Lock the park brake.
5. Stop the engine.
6. Remove the key.
7. Wait for engine and all moving parts to stop before you leave the operator's seat.
8. Close fuel shut-off valve, if your machine is equipped.
9. Disconnect the negative battery cable or remove the spark plug wire(s) (for gasoline engines) before servicing the machine.

Practice Safe Maintenance

- Only qualified, trained adults should service this machine.
- Understand service procedure before doing work. Keep area clean and dry.
- Do not operate the engine in a confined space where dangerous carbon monoxide fumes can collect.
- Never lubricate, service or adjust the machine or attachment while it is moving. Keep safety devices in place and in working condition. Keep hardware tight.
- Keep hands, feet, clothing, jewelry, and long hair away from any moving parts, to prevent them from getting caught.
- Lower any attachment completely to the ground or to an existing attachment mechanical stop before servicing the attachment. Disengage all power and stop the engine. Lock park brake and remove the key. Let machine cool.

Safety

Practice Safe Maintenance

- Disconnect battery or remove spark plug wire (for gasoline engines) before making any repairs.
- Before servicing machine or attachment, carefully release pressure from any components with stored energy, such as hydraulic components and springs.
- Release hydraulic pressure by lowering attachment or cutting units to the ground or to a mechanical stop and move hydraulic control levers.
- Securely support any machine or attachment elements that must be raised for service work. Use jack stands or lock service latches to support components when needed.
- Never run engine unless park brake is locked.
- Keep all parts in good condition and properly installed. Fix damage immediately. Replace worn or broken parts. Replace all worn or damaged safety and instruction decals.
- Check all hardware at frequent intervals to be sure the equipment is in safe working condition.
- Do not modify machine or safety devices. Unauthorized modifications to the machine or attachment may impair its function and safety.
- Do not put large clumps of material into the hopper. Never reach in to the hopper without disconnecting the power first. If a blockage occurs, follow the proper procedure in the Preventing and Clearing Blockages section of this manual.
- When lifting bagged material, use proper lifting technique. Lift the load using your leg muscles not your back. Do not lift bulky or heavy loads alone. Lift as a team.

Wear Appropriate Clothing



- Always wear eye protection when operating the machine.
- Wear close fitting clothing and safety equipment appropriate for the job.
- While operating this machine, always wear substantial footwear and long trousers. Do not operate the equipment when barefoot or wearing open sandals.
- Wear a suitable protective device such as earplugs. Loud noise can cause impairment or loss of hearing.

Read Chemical Container Label

- Chemicals can be dangerous. Improper selection or use can injure persons, animals, plants, soils or other property. Select the right chemical for the job and handle and apply with care.

Read Chemical Container Label

- Read the instructions, precautions, and warnings on the container label before opening. Use the product strictly according to label directions for specific applications, in the amounts specified, at the times specified and only when needed.
- Keep the container closed tightly except when preparing the mix.
- Do not remove labels from chemical containers. Store all chemicals in their original containers.
- Do not mix chemicals unless stated on the container label.
- Store chemicals when not in use according to the container label.

Handle Chemical Products Safely

- Direct exposure to hazardous chemicals can cause serious injury.
- Potentially hazardous chemicals used with John Deere equipment include pesticides, herbicides and fungicides.
- A Material Safety Data Sheet (MSDS) provides specific details on chemical products: physical and health hazards, safety procedures, and emergency response techniques.
- The MSDS should be obtained from the chemical dealer at the time of the chemical purchase.
- Check the MSDS before beginning any job using a hazardous chemical. Know exactly what the risks are and how to do the job safely. Always wear recommended personal protection equipment.


Handling Waste Product and Chemicals

Waste products, such as, used oil, fuel, coolant, brake fluid and batteries, can harm the environment and people:

- Do not use beverage containers for waste fluids -someone may drink from them.
- See your local Recycling Center or authorized dealer to learn how to recycle or get rid of waste products.
- A Material Safety Data Sheet (MSDS) provides specific details on chemical products: physical and health hazards, safety procedures, and emergency response techniques. The seller of the chemical products used with your machine is responsible for providing the MSDS for that product.

Assembly

Parts in Kit



Parts not shown to scale

Spreader Assembly

Description	Letter	Qty
Spreader Assembly with Controller	A	1
SMV Sign	B	1
Display	C	1
Display Bracket	D	1
Bracket Receiver	E	1
P-clamp Bracket	F	1


Wiring Kit

Description	Qty
Display Cable	1
Battery Harness	1
Power Harness	1
Screws, M5 x 8mm	2
Washers, M5	2
Bolt, 5/16 in. Truss Head	2
Nut, 5/16 in. Flange	2
Bolt, 3/8 in. Flange	1
Nut, 3/8 in. Flange	1
P-clamp	1
6 in. wire ties	10

Installation

Install Display and Wire Harness


1. Remove the LH side engine cover and operator station platform to improve access to the main chassis harness and ensure safe and proper harness routing.
2. Starting with the battery harness, route the harness along the positive battery cable and secure with a wire tie near the yellow tape (A).




3. Insert the mating SAE connector through the opening and into the battery compartment with the existing wire harness bundle and connect it to the battery harness.
4. Following the existing wire harness bundle, route the power harness along left hand side of engine, behind the engine, and over to the right-hand side of the tractor.



5. Locate and disconnect the fuel pump connector (B).




6. Plug the wire harness pigtail (C) in-line with the fuel pump connectors.




7. Continue routing the power harness under the operator station platform to the ROPS at the right rear of the tractor by following the main chassis harness. Secure the power harness to the main chassis harness at least every 10" and on both ends of a bend.

NOTICE: While securing the power harness ensure that no wires/conduit are in direct contact with any moving parts and/or high temperature components.

8. Install the bracket receiver (D) to the p-clamp bracket (E) using two 5/16 in. x 1/2 in. truss head screws (F) and two 5/16 in. flange nuts (G). Attach the p-clamp bracket to the p-clamp using one 3/8 in. x 1 in. flange bolt (H) and one 3/8 in. flange nut (J).




9. Mount the p-clamp (K) to the front of operator assist handle as shown so that the receiver bracket is sitting forward of the cup holder.




10. Attach the display cable (L) to the connector on the rear of the display (M).

NOTE: Hand tighten the connector coupling nut to 0.5-1.0 ft-lb. Be careful not to cross thread the nut on the plastic threads. Do not twist the overmolded portion of the connector, only twist the metal coupling nut or damage may occur to the display connector pins.




11. Install the Display (N) to the Mounting Bracket (P) using two M5 x 8 pan head screw (Q) and two M5 washers (R).

NOTE: Tighten the screws to 4-5 ft-lb. Do not over tighten or damage may occur to the threaded inserts and plastic housing.



12. Mount the display by sliding the bracket into the spade mount and pressing down firmly. Route the display cable (S) along the 3pt position lever and connect to the power harness (T).

NOTE: Place any extra harness length into the storage compartment away from moving parts.



13. Connect the battery harness to the battery. The black harness wire connects to the negative battery terminal and the red harness wire connects to the positive battery terminal. The wires should exit the battery terminals toward the center of the battery.

NOTE: Ensure positive battery terminal boot is covering the battery terminal and no exposed metal is visible.

Install Spreader

See Ballasting Machine in your tractor operator's manual to determine the number of front weights required to ballast the tractor.

Attaching Spreader to Tractor

1. Park machine safely. (See Parking Safely in Safety section.)
2. Lower tractor lift link to lowest position.
3. Mount drop spreader on 3-Point hitch..
4. Insert SMV sign space in to the holder located on the left rear of the spreader.
5. Connect the 2 connectors on the spreader harness to the power harness.

Operation

Determine Vehicle Load Capacity

Use the vehicle's Operator's Manual to determine vehicle load capacity.



CAUTION: Avoid Injury! Overloading the vehicle causes loss of control and causes serious injury or death.

- Do not allow the Gross Vehicle Weight () to exceed the Gross Vehicle Weight Rating (GVWR) of the vehicle.
- Remove excess weight before operating vehicle.

NOTE: Optional equipment and attachments that are not standard equipment reduce your cargo box capacity; so they must be included when determining gross vehicle weight.

Use Correct Tires and Inflation

See specification section of this operators manual for spreader weight.

See tire descriptions and inflation pressures for load conditions in the specifications section of the vehicles operator's manual.

Calculate Application Rate



CAUTION: Help prevent severe bodily injury or death, failure to observe the recommendations in the vehicle operator's manual may result in loss of stability and operator control.


- Determine the vehicle speed that will be used.
- Place the container on a scale and make note of the weight or tare the scale.
- Measure the weight / mass of the material spread in 30 seconds. Subtract the weight / mass of the container.
- Divide lbs measured in 30 seconds by the intended speed of the vehicle in mph, and multiply by 6.06 to get lbs per 1000 ft².

$$\frac{\text{lbs per 30 seconds}}{\text{intended vehicle speed in mph}} \times 6.06 = \frac{\text{lbs}}{1000\text{ft}^2}$$

$$\frac{\text{kg per 30 seconds}}{\text{intended vehicle speed in kmph}} \times 3.5 = \frac{\text{kg}}{1000\text{m}^2}$$

Metering Gate Adjustment

To adjust the opening on the metering gate, squeeze lever (A) downward and rotate handle (B) to desired opening. There are 6 gate positions, each position increments the gate by approximately 1/4".



Preventing and Clearing blockages.

Material flows best when material is free of large clumps. If a blockage occurs or material is not spreading, proceed with the following steps until the blockage is cleared.

1. Open the metering gate to a larger position and attempt to spread material again.
2. Turn on the vibrator to help break apart any clumps of material and help the material to flow into the rotor tray. Attempt to spread again.
3. If the auger is stalled and jammed. Follow reverse auger direction instructions.
4. Disconnect power from the spreader. Remove lid and open top grate. Remove any clumped material from the hopper.

Spreader Components

Hopper	5 cu. ft. capacity, stainless steel hopper
Vibration Motor	Variable speed 12V DC vibrating motor that helps material flow
Controller	Controls the vibration motor and auger motor
Display	2.4 in. monochrome OLED with 7 buttons
Auger Motor	Variable speed 12V DC motor drives the auger that moves material out of the hopper

Operation

Spreader Feature

Auger Reverse/Jam Clear
Error Message/Diagnostics
Vibratory motor for improved material flow
Variable Speed Auger
Adjustable gate for precise material application


Turning On Display



The vehicle key must be in the “On” or “Run” position for the display to turn on.

When turned on, a splash screen will appear as the software loads. The operation page will appear when loading is complete. The spreader is now ready to operate.


Navigation

Control the spreader using the buttons on the display. Button functionality is described in the table below and varies by screen.



Button #	Button Functions		
1	ON	Spinner/ Auger On	Press the “ON” button to turn on the auger.
2	OFF	Spinner/ Auger Off	Press the “OFF” button to turn off the auger.
3	OPEN/ ON	Gate Open/ Vibe ON	Press the OPEN/ON button to turn on the vibratory motor.
4	CLOSE/ OFF	Gate Close/Vibe OFF	Press the CLOSE/OFF button to turn off the vibratory motor.
5		Down Arrow	Press to decrease the speed of the auger.
6		Up Arrow	Press to increase the speed of the auger.
7	MENU	Menu Button	Press to enter the menu.

From the operation page, an operator can power on the spreader, enter the menu, or spinner speed.



Operation

Default Motor Controls


Starting and Stopping Spreader	Press the ON button to turn on the spinner/auger. Press the OFF button to turn off the spinner/auger
Gate/Vibe Control	Press the OPEN/ON button to open the gate or to turn on the vibe. Press the CLOSE/OFF button to close the gate or to turn off the vibe.
Adjusting Motor Speed	Press the bottom left button (down arrow) to decrease the speed of the motor in 11% increments. Press the bottom mid button (up arrow) to increase the speed of the motor in 11% increments.
Entering the Menu	Press the bottom right button (menu) to enter the menu.

NOTE: In order to control the Gate/Vibratory Motor the Spinner/Auger must be active, if it is not active the Gate/Vibe label state will blink indicating the motor is disabled.

Main Menu

Pressing the menu button will enter the main menu.

Once in the main menu, the user can select the following:



Menu Options

Diagnostics	Review the warning and fault list.
Maintenance	Displays maintenance menu with options to reverse auger.
Settings	Adjusts the parameters of the display.
System	Display system's voltage and temperature.
Support	Displays support information.
Controller Info	Displays controller information
Display Info	Displays system information.
Exit	Returns to the home page.

Maintenance Menu

Reverse Auger

The reverse auger feature allows users to reverse the auger in case of a jam.

To activate the reverse auger feature:

1. Select maintenance for the main menu.
2. Press start. The auger will pulse 3 times and the start button changes to pulsing to indicate the auger is turning.



3. If the auger needs to be reversed further, press start again and wait for the reverse cycle to complete.
4. Press the exit button to return to the main menu.
5. If jam cannot be cleared, refer to cleaning auger section.

Operation

Settings Menu

Selecting settings from the main menu will enter the settings menu.

From the settings menu, the user can select the following:

- Display to select the brightness level.
- CAN, to enable/disable the CAN terminator resistor.
- Exit, go back to main menu.

Display Screen Messages

During operation a message may appear describing a potential issue or problem.

Motor Over Current	<p>A motor is drawing too much current. Spreader will shut down, display an error message, and prompt the operator to reset the spreader.</p> <p>The spinner disk may be jammed and needs to be cleared.</p>
Motor Open Circuit	<p>This message is displayed when a motor is disconnected. Ensure that all harnesses are installed correctly, and connectors are fully seated. Ensure that the status light on the motor controller is green.</p>
Voltage High	<p>This message is displayed when the controller is receiving a voltage higher than 16V. Please check battery voltage.</p>
Voltage low	<p>This message is displayed when the controller is receiving a voltage lower than 9V. Please check battery voltage.</p>
No Comm	<p>This message is displayed when there is a loss of communication with the motor controller. Ensure that all harnesses are installed correctly, and connectors are fully seated. Ensure that the status light on the motor controller is green.</p>

Spreading

NOTE: Always use the hopper cover to prevent moisture buildup. Do not let spreader sit idle with material in the hopper for an extended period of time. This can cause material to compact, reduce or stop the flow of material and cause permanent hopper damage.



IMPORTANT: Never operate near pedestrians. Never exceed 10 mph while spreading. This spreader is for rock salt, ice melt, fertilizer or lime only.



CAUTION: DO NOT leave unused material in hopper. Material can freeze or solidify, causing unit to not work properly. Empty and clean after each use.




CAUTION: Disconnect electric and/or hydraulic power and tag out if required before servicing or performing maintenance.


Maintenance

Adjusting Chain Tension

1. Remove bolt (E) and lift bottom of shield until it is rotated about 90° and pull out.



2. Loosen three bolts (F) and slide the motor mount plate rearward. The slack-side (G) tension should be 1/4" to 5/16" (6mm to 8mm) of midspan movement. Re-tighten three bolts.



Chain Lubrication

Schedule chain lubrication:

- Apply lubrication upon removal from storage
- Reapply lubrication every 20 hours of use
- Apply lubrication prior to storage

Cleaning

To protect from corrosion, clean spreader after every use with warm water and mild detergent.

Do not leave material in the spreader.

Removal and Storage

Removing Spreader From Tractor

1. Park the machine safely. (See Parking Safely in Safety section.)
2. Empty the spreader.
3. Lower tractor lift link to lowest position.
4. Disconnect the spreader harness from the power harness and attach to the mating connector on the spreader for storage.
5. Disconnect spreader from tractor 3-Point hitch.
6. Disconnect the display cable from the power harness and pull the display bracket out of the bracket receiver. Store display and bracket inside.
7. Remove any added front ballast from machine.

Troubleshooting

The Display Module and Control Module work as a system and communicate with each other over the CAN bus. Both modules should be powered up at the same time for proper functionality.

Symptom	Troubleshooting Guide
Control Module and/or Display Module does not turn on Control Module status light is off Display Module screen is off and/or status light is off	<ol style="list-style-type: none"> 1. Ensure connections are fully seated. 2. Remove front wire harness. Check for 12v at pins A-J at rear connection attachment point. 3. If no voltage, vehicle has insufficient power or ground connection. <ul style="list-style-type: none"> • If 12V, check for 12v at pins at pins 2-3 on display side of connector. • If no voltage, replace wire harness. • If 12v, display is faulty. Replace display.
No Communications	<p>Check for 12V at controller pins M1-M4, if no voltage check:</p> <ul style="list-style-type: none"> • Fuse on Gator Harness • Chassis harness connection • Spreader harness connection.
No Communications No CAN communication between Control Module and Display Module	<ul style="list-style-type: none"> • Display harness connection. • Spreader harness connection. • Check continuity from control module pin A2 to spreader harness pin 4 • Check continuity from control module pin C2 to spreader harness pin 5
Vibratory Motor does not turn on	<ul style="list-style-type: none"> • A vibratory motor that has not been recently used can seize. A few light taps with a hammer or mallet on the motor will typically free the motor
Material does not flow through gate	<ul style="list-style-type: none"> • Open the gate to the next position to increase flow • Material that has gotten damp may clump and will not flow as well as dry material. Always operate the spreader with the lid installed

Display Module Error Codes

SPN	Error	Description	Troubleshooting Guide
1100	High Temperature Fault	Internal temperature above 75C	The module will stop operating the spreader if the internal temperature rises above 75C. This is a latching fault to protect the electronics. Reduce the module's exposure to high temperatures to allow its internal temperature to fall below 75C. The module must be power cycled to recover from a high temperature fault.
1101	High Temperature Warning	Internal temperature above 65C	No action is necessary. The module will continue operating the spreader with an internal temperature between 65C and 75C but will stop operating the spreader if the internal temperature rises above 75C.
1102	Low Temperature Fault	Internal temperature below -30C	The module will stop operating the spreader if the internal temperature falls below -30C. This is a latching fault to protect the electronics. Reduce the module's exposure to low temperatures to allow its internal temperature to rise above -30C. The module must be power cycled to recover from a low temperature fault.
1103	Low Temperature Warning	Internal temperature below -20C	No action is necessary. The module will continue operating the spreader with an internal temperature between -20C and -30C but will stop operating the spreader if the internal temperature falls below -30C.

SPN	Error	Description	Troubleshooting Guide
1104	High Voltage Fault	System voltage above 19V	The module will stop operating the spreader if the system voltage rises above 19V. This is a latching fault to protect the electronics. The module must be power cycled to recover from a high voltage fault. Note that the Display Module high voltage fault is not the same as the Control Module high voltage fault.
1105	High Voltage Warning	System voltage above 18V	No action is necessary. The module will continue operating the spreader with a system voltage between 18V and 19V but will stop operating the spreader if the system voltage rises above 19V. Note that the Display Module high voltage warning is not the same as the Control Module high voltage warning.
1106	Low Voltage Fault	System voltage below 6.5V	The module will stop operating the spreader if the system voltage falls below 6.5V. This is a latching fault to protect the electronics. The module must be power cycled to recover from a low voltage fault. Note that the Display Module low voltage fault is not the same as the Control Module low voltage fault.
1107	Low Voltage Warning	System voltage below 7V	No action is necessary. The module will continue operating the spreader with a system voltage between 7V and 6.5V but will stop operating the spreader if the system voltage falls below 6.5V. Note that the Display Module low voltage warning is not the same as the Control Module low voltage warning.
1108	Lost Communication Fault	Lost CAN communication	The module will stop operating the spreader if the CAN communication with the Motor Controller is lost. Make sure all wiring harness connections are secure and all wiring is intact and undamaged. The modules must be power cycled to recover from a lost communication fault.
9999	Unknown Fault	Unknown Fault	Contact Agri-Fab for support.

Control Module Error Codes

The Control Module for the Drop Spreader contains two motor drivers: MD1 controls the Auger and MD2 controls the vibratory motor. The errors that reference MD1 are related to the auger. The errors that reference MD2 are related to the vibratory motor.

SPN	Error	Description	Troubleshooting Guide
6100	MD1 Open Circuit	Motor Driver 1 output is disconnected	The motor driver checks if a load is connected between the positive and negative motor driver outputs before attempting to drive the motor. This is a latching fault to protect the electronics. Verify that the connections at the controller terminals are properly secured, the wiring harnesses are not damaged, and all wiring harness connectors are properly connected. Verify that the motor is not damaged. The module must be power cycled to recover from the open circuit fault.
6101	MD1 Over Current	Motor Driver 1 current draw above 15A	The motor driver will stop operating the spreader if the output current goes above 15A. This is a latching fault to protect the electronics. Verify that the motor is not damaged. A heavily loaded or jammed auger can result in a very high current draw. Reduce the load on the auger or clear the jam before power cycling the module to recover from the over current fault.

SPN	Error	Description	Troubleshooting Guide
6102	MD1 Short to Battery	Motor Driver 1 output shorted to battery positive	The motor driver checks if the positive or negative motor driver outputs are shorted to battery positive (12V) before attempting to drive the motor. This is a latching fault to protect the electronics. Verify that the connections at the controller terminals are not being bridged by any conductive material. Verify that the wiring harnesses are not damaged and all wiring harness connectors are properly connected.
6103	MD1 Short to Ground	Motor Driver 1 output shorted to battery negative	The motor driver checks if the positive or negative motor driver outputs are shorted to battery negative (ground or 0V) before attempting to drive the motor. This is a latching fault to protect the electronics. Verify that the connections at the controller terminals are not being bridged by any conductive material. Verify that the wiring harnesses are not damaged and all wiring harness connectors are properly connected.
6104	MD1 TLE OverTemp Fault	Motor Driver 1 internal temperature above 75C	The module will stop operating the spreader if the internal temperature rises above 75C. This is a latching fault to protect the electronics. Reduce the module's exposure to high temperatures to allow its internal temperature to fall below 75C. The module must be power cycled to recover from a high temperature fault.
6105	MD1 TLE OverTemp Warning	Motor Driver 1 internal temperature above 65C	No action is necessary. The module will continue operating the spreader with an internal temperature between 65C and 75C but will stop operating the spreader if the internal temperature rises above 75C.
6106	MD1 FET Overtemp Fault	Motor Driver 1 FET temperature above 75C	The module will stop operating the spreader if the internal temperature rises above 75C. This is a latching fault to protect the electronics. Reduce the module's exposure to high temperatures to allow its internal temperature to fall below 75C. The module must be power cycled to recover from a high temperature fault.
6107	MD1 FET Overtemp Warning	Motor Driver 1 FET temperature above 65C	No action is necessary. The module will continue operating the spreader with an internal FET temperature between 65C and 75C but will stop operating the spreader if the internal FET temperature rises above 75C.
6108	MD1 High VBAT Fault	Motor Driver 1 voltage above 18V	The module will stop operating the spreader if the system voltage rises above 18V. This is a latching fault to protect the electronics. The module must be power cycled to recover from a high voltage fault. Note that the Control Module high voltage fault is not the same as the Display Module high voltage fault.
6109	MD1 High VBAT Warning	Motor Driver 1 voltage above 16V	No action is necessary. The module will continue operating the spreader with a system voltage between 16V and 18V but will stop operating the spreader if the system voltage rises above 18V. Note that the Control Module high voltage warning is not the same as the Display Module high voltage warning.
6110	MD1 Low VBAT Fault	Motor Driver 1 voltage below 8V	The module will stop operating the spreader if the system voltage falls below 8V. This is a latching fault to protect the electronics. The module must be power cycled to recover from a low voltage fault. Note that the Control Module low voltage fault is not the same as the Display Module low voltage fault.
6111	MD1 Low VBAT Warning	Motor Driver 1 voltage below 9V	No action is necessary. The module will continue operating the spreader with a system voltage between 8V and 9V but will stop operating the spreader if the system voltage falls below 8V. Note that the Control Module low voltage warning is not the same as the Display Module low voltage warning.

SPN	Error	Description	Troubleshooting Guide
6112	MD1 No Communication	Motor Driver 1 is not responding at power up	The module will not operate if it cannot communicate with the internal motor driver at power up. Power cycle the module. If the error is still active contact Agri-Fab for support.
6113	MD1 Lost Communication	Motor Driver 1 has lost communication for 10 seconds	The module will stop operating if it loses communication with the internal motor driver for more than 10 seconds. Power cycle the module. If the error is still active contact Agri-Fab for support.
6200	MD2 Open Circuit	Motor Driver 2 output is disconnected	The motor driver checks if a load is connected between the positive and negative motor driver outputs before attempting to drive the motor. This is a latching fault to protect the electronics. Verify that the connections at the controller terminals are properly secured, the wiring harnesses are not damaged, and all wiring harness connectors are properly connected. Verify that the motor is not damaged. The module must be power cycled to recover from the open circuit fault.
6201	MD2 Over Current	Motor Driver 2 current draw above 15A	The motor driver will stop operating the spreader if the output current goes above 15A. This is a latching fault to protect the electronics. Verify that the motor is not damaged. A vibratory motor that has not been recently used can seize. A few light taps with a hammer or mallet on the motor will typically free the motor. Attempt to free the vibratory before power cycling the module to recover from the over current fault.
6202	MD2 Short to Battery	Motor Driver 2 output shorted to battery positive	The motor driver checks if the positive or negative motor driver outputs are shorted to battery positive (12V) before attempting to drive the motor. This is a latching fault to protect the electronics. Verify that the connections at the controller terminals are not being bridged by any conductive material. Verify that the wiring harnesses are not damaged and all wiring harness connectors are properly connected.
6203	MD2 Short to Ground	Motor Driver 2 output shorted to battery negative	The motor driver checks if the positive or negative motor driver outputs are shorted to battery negative (ground or 0V) before attempting to drive the motor. This is a latching fault to protect the electronics. Verify that the connections at the controller terminals are not being bridged by any conductive material. Verify that the wiring harnesses are not damaged and all wiring harness connectors are properly connected.
6204	MD2 TLE OverTemp Fault	Motor Driver 2 internal temperature above 75C	The module will stop operating the spreader if the internal temperature rises above 75C. This is a latching fault to protect the electronics. Reduce the module's exposure to high temperatures to allow its internal temperature to fall below 75C. The module must be power cycled to recover from a high temperature fault.
6205	MD2 TLE OverTemp Warning	Motor Driver 2 internal temperature above 65C	No action is necessary. The module will continue operating the spreader with an internal temperature between 65C and 75C but will stop operating the spreader if the internal temperature rises above 75C.
6206	MD2 FET Overtemp Fault	Motor Driver 2 FET temperature above 75C	The module will stop operating the spreader if the internal temperature rises above 75C. This is a latching fault to protect the electronics. Reduce the module's exposure to high temperatures to allow its internal temperature to fall below 75C. The module must be power cycled to recover from a high temperature fault.

SPN	Error	Description	Troubleshooting Guide
6207	MD2 FET Overtemp Warning	Motor Driver 2 FET temperature above 65C	No action is necessary. The module will continue operating the spreader with an internal FET temperature between 65C and 75C but will stop operating the spreader if the internal FET temperature rises above 75C.
6208	MD2 High VBAT Fault	Motor Driver 2 voltage above 18V	The module will stop operating the spreader if the system voltage rises above 18V. This is a latching fault to protect the electronics. The module must be power cycled to recover from a high voltage fault. Note that the Control Module high voltage fault is not the same as the Display Module high voltage fault.
6209	MD2 High VBAT Warning	Motor Driver 2 voltage above 16V	No action is necessary. The module will continue operating the spreader with a system voltage between 16V and 18V but will stop operating the spreader if the system voltage rises above 18V. Note that the Control Module high voltage warning is not the same as the Display Module high voltage warning.
6210	MD2 Low VBAT Fault	Motor Driver 2 voltage below 8V	The module will stop operating the spreader if the system voltage falls below 8V. This is a latching fault to protect the electronics. The module must be power cycled to recover from a low voltage fault. Note that the Control Module low voltage fault is not the same as the Display Module low voltage fault.
6211	MD2 Low VBAT Warning	Motor Driver 2 voltage below 9V	No action is necessary. The module will continue operating the spreader with a system voltage between 8V and 9V but will stop operating the spreader if the system voltage falls below 8V. Note that the Control Module low voltage warning is not the same as the Display Module low voltage warning.
6212	MD2 No Communication	Motor Driver 2 is not responding at power up	The module will not operate if it cannot communicate with the internal motor driver at power up. Power cycle the module. If the error is still active contact Agri-Fab for support.
6213	MD2 Lost Communication	Motor Driver 2 has lost communication for 10 seconds	The module will stop operating if it loses communication with the internal motor driver for more than 10 seconds. Power cycle the module. If the error is still active contact Agri-Fab for support.
6400	Motor Driver Mismatch Version	Motor Driver 1 and Motor Driver 2 have different software versions	The module will not operate if the software loaded in the motor drivers does not match. Power cycle the module. If the error is still active contact Agri-Fab for support.
6401	Spreader Type Memory Corruption	Spreader Type stored in memory is not valid	The module will not operate if the software does not load the proper spreader type from internal memory. Power cycle the module. If the error is still active contact Agri-Fab for support.

Wiring Diagram

Spreader Harness Connections

2 pin Connector

pin 1	Battery Positive
pin 2	Battery Negative

6 pin Connector

pin 1	Switched Battery Positive
pin 2	Battery Negative
pin 3	Ignition
pin 4	CAN-
pin 5	CAN+
pin 6	No Connect

Control Module Output Terminals

A	Auger Motor Negative
B	Auger Motor Positive
C	Battery Negative
D	Battery Positive
E	Vibratory Motor Negative
F	Vibratory Motor Positive
G	No Connect
H	No Connect

Warranty

John Deere Quality Continues with Quality Service

John Deere provides a process to handle your questions or problems, should they arise, to ensure that product quality continues with quality parts and service support.

Follow the steps below to get answers to any questions you may have about your product.

1. Refer to your attachment and machine operator manuals.
2. In North America or Canada, call Agri-Fab Customer Service at 1-800-448-9282 and provide product serial number (if available) and model number.

Warranty

Limited Warranty for New John Deere Licensed Products

Agri-Fab's spreaders are guaranteed to be free from defects in material and workmanship from the date of purchase for 1 year residential use, 6 months commercial use, provided that the purchaser properly assembles, installs, uses and maintains the products in accordance with this manual.


Purchaser's failure to adhere to such requirements will void the warranty. To the extent permitted by applicable law, all other warranties, representations, obligations and conditions, expressed or implied, including but not limited to implied warranties of merchantability, fitness for any particular purpose and non-infringement, are hereby disclaimed and excluded.

Any product which does not meet warranty shall, as purchaser's sole and exclusive remedy, be repaired or replaced by Agri-Fab. This warranty is non transferable.

In addition, our warranty does not cover:

- Labor charges
- Loss or consequential, incidental or special damages of any kind.

This product was manufactured by Agri-Fab, Inc, a John Deere Licensee. If you have any questions or concerns with the assembly, installation, or operation of this attachment, see your local John Deere dealer or call Agri-Fab at 1-800-448-9282 for assistance.



This page intentionally left blank

This page intentionally left blank