


REPAIR PARTS FOR BROADCAST SPREADER MODEL 45-02111



REPAIR PARTS LIST FOR BROADCAST SPREADER MODEL 45-02111

REF. NO.	PART NO.	QTY.	DESCRIPTION	REF. NO.	PART NO.	QTY.	DESCRIPTION
1	44466	1	Hopper	32	43070	3	Washer, Flat 3/8" *
2	43882	6	Rivet - Stainless	33	41576	2	Bolt, Hex 3/8-16 x 1-3/4" Lg. Gr. 5
3	62482	1	Ass'y - Guide Closure	34	44469	1	Rod, Flow Control
4	44462	1	Tube Frame	35	23525	2	Brace, Hitch
5	23753	1	Slide Gate Angle Bracket	36	23762	1	Shaft Support Plate
6	23758	1	Slide Gate Bracket	37	1509-069	12	Bolt, Hex 1/4-20 x 1-3/4"
7	43082	5	Nut, Hex Lock 3/8-16 Thd.*	38	43866	2	Bolt, Hex 1/4-20 x 5/8" Lg. Gr. 5
8	23756	1	Flow Control Link	39	1543-069	9	Washer, Nylon
9	43013	16	Nut, Hex Lock 1/4-20 Thread*	40	43088	9	Washer, Flat 1/4" Std.*
10	43808	1	Tube Crossover	41	23755	1	Gage, Flow Control
11	43084	2	Bolt, Hex 5/16-18 x 1-3/4" Lg.	42	23754	1	Bracket, Flow Control Mount
12	43086	2	Lock Washer, 5/16" *	43	62474	1	Gear Ass'y.
13	43064	2	Nut, Hex Lock 5/16-18 Thd.*	44	23757	1	Flow Control Arm
14	44487	1	Tube, Hitch	45	44101	1	Cotter Pin 3/32" x 3/4" Lg.
15	44456	1	Wheel, Ass'y 14" x 4"	46	23533	1	Plate, Closure
16	44457	1	Wheel, Ass'y 14" x 4" W/ Hole	47	43000	1	Spring, Extension
17	23687	1	Bracket, Hitch	48	43848	1	Grip, Flow Control Arm
18	23522	1	Shaft, Axle	49	43087	2	Bolt, Hex 3/8-16 x 1-1/4" Lg.*
19	43851	2	Pin, Spring 3/16" Dia. x 1.25" Lg.	50	43093	1	Cotter Pin, 1/8" x 1-1/2" Lg.
20	43871	1	Bushing, Axle Shaft	51	43009	4	Washer 1-5/8" O.D. x 25/32" I.D.
21	1540-032	5	Washer, Flat .78" I.D.	52	43849	1	Knob, Plastic 1/4-20 Thread
22	1540-162	1	Washer, Flat 3/4"	53	44285	1	Bushing Delrin 3/8 I.D.
23	44798	2	Bearing Flange	54	43054	1	Bolt, Hex 3/8-16 x 2" Lg. Gr. 5
24	44474	2	Spacer	55	43003	2	Lock Washer, 3/8" *
25	23524	1	Shaft, Sprocket	56	43962	1	Vinyl Hopper Cover, Optional
26	04367	1	Spreader Plate	57	44566	1	Spring, Torsion
27	43850	1	Pin, Spring 1/8" x 5/8" Lg.	58	43012	1	Bolt, Hex 1/4-20 x 3/4" Lg. Gr. 5
28	44468	1	Sprocket - 6 T.	59	46055	1	Pin, Spring 1/8" x 1" Lg.
29	43852	1	Bushing, Nylon 3/8 ID	60	44950	1	Bolt, Carriage 1/4-20 x 3/4" Lg.
30	23766	1	Sleeve, Agitator	61	R19111116	3	Washer, Flat 5/16"
31	43878	1	Wire, Agitator		46512	1	Owner's Manual

Purchase common hardware locally.

* Assembly
 * Operation
 * Maintenance
 * Repair Parts

REPAIR PARTS
 303 West Raymond
 Sulligent, AL 36851
 205-728-3388
 205-728-3389

FORM NO. 46512