


# REPAIR PARTS



REF	QTY	PART NO	DESCRIPTION	REF	QTY	PART NO	DESCRIPTION
1	1	45282	Hopper	29	1	43010	Pin, Cotter 1/8 X 1-1/4
2	2	45802G	Wheel	30	1	43093	Pin, Cotter 1/8 x 1-1/2
3	1	27313YL4	Cross Brace	31	1	48934	Hairpin, Agitator
4	1	2-536YL4	Tube, Hitch Support	32	13	47189	Nut, Hex 1/4-20 Nylock
5	1	2-535YL4	Tube, Hitch Support	33	6	1543-69	Washer, Nylon .328 x .75 x .9
6	2	2-537YL4	Tube, Hopper Support	34	9	43088	Washer, .312 x .734 x .065
7	2	40665	Bolt, Hex 1/4-20 X 3-1/2	35	2	R19171616	Washer, .531 x 1 x .0598
8	2	28329YL4	Brace, Hopper	36	1	43343	Pin, Hair Cotter 3/32 x 2-5/16
9	1	04367	Spreader Impeller	37	5	49449	Plug, 1" OD Tube
10	1	41930	Rod, Flow Control	38	2	47963	Bearing, Hex Flange .50ID
11	1	2-1351	Axle, .500 OD	39	1	44285	Bushing, 3/8" (Hopper)
12	1	41937YL4	Tube, Hitch	40	1	42839	Bushing, 3/8" Plastic
13	1	27322BL1	Bracket, Flow Control Mount	41	1	47623	Pin, Hitch 3/8" x 2-3/4
14	1	23687BL1	Bracket, Hitch	42	1	43848	Grip, Control Arm
15	1	27314BL3	Arm, Flow Control	43	1	47141	Nut, Wing 1/4-20
16	1	45344	Plate, Flow	44	1	4-138	Pin, Cotter SS 5/32 x 2
17	1	44468	Sprocket	45	1	43850	Pin, Roll 1/8 x 5/8
18	1	44672	Bushing, 1/2 Axle Shaft	46	1	42347	Spring, Torsion
19	1	62798	Slotted Gear	47	1	43661	Bolt, Hex 1/4-20 x 1
20	1	28323	Shaft, Spreader	48	2	43840	Bolt, Hex 5/16-18 x 1-1/4
21	2	49870	Bolt, Hex 1/4-20 x 2-1/2	49	2	47810	Nut, Hex 5/16-18 Nylock
22	2	46699	Bolt, Hex 1/4-20 x 2	50	1	23625	Spacer, .380ID x .620OD x .27
23	6	1509-69	Bolt, Hex 1/4-20 x 1-3/4	51	2	48402	Plug, 1/4"
24	1	44950	Bolt, Carriage 1/4-20 x 3/4	52	2	44665	Pin, Roll 5/32 x 1-1/4
25	1	24858	Stop, Adjustable	53	3	44137	Washer, .518 x 1 x .02
26	2	46847	Spacer, .410ID x .630OD x .43	54	1	41316	Hopper Cover (Sold Separately)
27	2	4-14	Spacer, .53ID x 1.40 LG	1	1	3-500	Owner's Manual
28	1	44101	Pin, Cotter 3/32 x 3/4				